

ULTIMEA

FULL HD PROJECTOR QUICK START GUIDE

Apollo P40



Model No.: U0320

1080P

WE ARE READY TO HELP



support@ultimea.com

Prefer video tutorial?
Setup guidance video and
User Manuals on UTIMEA
website.



support.ultimea.com



@Ultimea_Official

+1 888-598-8875 (US) Mon-Fri 9am-5pm (PST)
+49 89-628-25828 (EU) Mon-Fri 9am-5pm (CET)

IMPORTANT: Before using the projector, make sure you read these instructions and the safety instructions in the online User Manual. Your product may differ from the illustrations on this sheet, but the instructions are the same.

Note: Due to HDCP protocol, Netflix, Amazon Prime and similar services can not be played by the projector wirelessly. Please use a Fire TV stick, Roku stick or Chromecast TM (not included) and connect it to the projector to use their streaming services.

1 Accessories List



Apollo P40



Remote
(Batteries not included)



Quick guide



AV Cable




Cable HD




Power Cable

2 Product




3 Remote Control



4 Quick Setup



4.1 Power On / Power Off

Plug in the AC power cord, click the power button on the operation panel of the machine or on the remote control and the projector will start to work.




4.2 Projector Installation


You can choose horizontal placement or hanger installation.




1 Front projection ceiling mount



3 Rear projection ceiling mount



2 Front projection table mount




4 Rear projection table mount


The projection screen can be played from 35" to 150".
The recommended projection screen is 50" to 100".
Ambient darkness will improve the clarity of the projected images.

4.3 Adjust the Image Projected On the Screen


Check the horizontal and vertical settings of the screen.




4.4 WiFi Settings




1. Click the settings icon on the homepage to enter the projector settings.



2. Select "WiFi" and click "OK" to confirm.




3. The network list will appear after searching for the network. Select the wireless network that needs to be connected and press the "OK" button to confirm.




4. Click the connect button after entering the password.

4.5 BT Settings



1. Click the settings icon on the homepage to enter the projector settings, select the "BT" click "OK" button to confirm.




2. Turn on BT and select the BT signal that needs to be connected.

5 Screen Mirroring

For iOS Device

1. Move the projector cursor to AirPlay on the homepage, select AirPlay and click the "OK" button.



Note: Make sure that the projector and mobile phone are connected to the same network.

2. The operation steps of the mobile phone are as follows:
No setting is required on the projector.




Step 1 : Open the Control Center and tap the Screen Mirroring on your iOS device.



Step 2 : Select the device U0320 to be cast from the searched devices.

For Android Device

1. Move the projector cursor to Miracast on the homepage, select Miracast and click the "OK" button.



2. Turn on the Android device, enter phone settings to find "Device Connectivity", click on "Wireless Display", search for U0320 of the projector and select U0320. Make sure that the projector and Android device are connected to the same network.




Note:

Due to HDCP protocol, Netflix, Amazon Prime and similar services can not be played by the projector wirelessly. Please use a Fire TV stick, Roku stick or Chromecast TM (not included) and it connect to the projector to use their streaming services.

6 Wired Connection to Devices

Fire TV Stick





How to connect the Fire TV stick to the projector:

1. Connect the TV stick to power using the USB cable.
2. Plug the stick to the HD port on the projector.
3. Select the HD option in the settings on the projector.
The content of the Fire TV stick will be displayed on the projection screen. Use the Fire stick's remote to select and stream your content.

6.1 HD Channel




Use an HD cable to connect the projector with a computer, game console, set-top box and other devices that support HD output and select HD option in settings.



Note: Due to type-C protocols, android device can not be played by HD cable connection.



6.2 AV Channel

Use an AV cable to connect the projector with a DVD player, set-top box and other devices that support AV output .



6.3 Multimedia Channel


After inserting the USB, select the movie, music, pictures or office file according to the type of file you need to play and enter the corresponding playback menu.



7 BT Speaker Mode


Turn on the projector and enter the homepage, use the remote control to select the BT speaker and press the "OK" button. The display will show BT speaker mode and enter 'waiting to pair'. You can connect to the projector (Name: BT-U0320) through the BT settings of the mobile device.

To use the projector function, press the return button to exit BT speaker mode. Now the machine will turn on and enter projector mode.



Speaker mode

Connecting....



Enjoy your new projector!