

Ultimea Aura

ULTIMEA














# A60 Pro


## USER MANUAL

User Manual / Bedienungsanleitung / Manuel d'utilisation /  
Manual de usuario / Manuale utente / Manual do utilizador /  
Gebruikershandleiding / Instrukcja obsługi / Användarhandbok /  
Kullanım kılavuzu / 取扱説明書 / 用户手册 / 使用者手冊 / 사용 설명서 /  
Panduan Pengguna / دليل المستخدم


Model No.: U2624

Product Name: Soundbar








2-3m / 6.6-9.8ft






or



SL-IN


SL-OUT




- EN Batteries Not Included.  
 DE Batterien nicht enthalten.  
 FR Piles non incluses.  
 ES Baterías no incluidas.  
 IT Batteria non inclusa.  
 PT Baterias não incluídas.  
 NL/BE Batterijen niet inbegrepen.  
 PL Bateria nie są dołączone.  
 SV Batterier ingår ej.  
 TR Piller dahil değildir.  
 JP 電池は含まれていません。  
 CN 電池不包含在內。  
 TC 電池不包含在內。  
 KO 배터리는 포함되지 않습니다.  
 ID Baterai tidak termasuk.  
 TH แบตเตอรี่ไม่รวมอยู่ด้วย  
 البطاريات غير مشمولة.

AR








eARC OPT Bluetooth® AUX USB




or



eARC OPT Bluetooth® AUX USB





or






## Phone Settings





or




|       |                                                                                                      |
|-------|------------------------------------------------------------------------------------------------------|
| EN    | Short press to select Bluetooth® channel, long press to disconnect.                                  |
| DE    | Kurz drücken, um den Bluetooth®-Kanal auszuwählen, lang drücken, um die Verbindung zu trennen.       |
| FR    | Appuyez brièvement pour sélectionner le canal Bluetooth®, appuyez longuement pour déconnecter.       |
| ES    | Presione brevemente para seleccionar el canal Bluetooth®, presione prolongadamente para desconectar. |
| IT    | Premere brevemente per selezionare il canale Bluetooth®, premere a lungo per disconnettere.          |
| PT    | Pressione rapidamente para selecionar o canal Bluetooth®, pressione longamente para desconectar.     |
| NL/BE | Kort indrukken om het Bluetooth®-kanaal te selecteren, lang indrukken om de verbinding te verbreken. |
| PL    | Krótko naciśnij, aby wybrać kanał Bluetooth®, przytrzymaj, aby rozłączyć.                            |
| SV    | Tryck kort för att välja Bluetooth®-kanal, tryck länge för att koppla bort.                          |
| TR    | Kısa basarak Bluetooth® kanalını seçin, uzun basarak bağlantıyı kesin.                               |
| JP    | 短く押してBluetooth®チャンネルを選択し、長押しして切断します。                                                                 |
| CN    | 短按选择蓝牙通道，长按断开连接。                                                                                     |
| TC    | 短按選擇藍牙通道，長按斷開連接。                                                                                     |
| KO    | 짧게 눌러 블루투스 채널을 선택하고, 길게 눌러 연결을 해제하세요.                                                                |
| ID    | Tekan singkat untuk memilih saluran Bluetooth®, tekan lama untuk memutuskan koneksi.                 |
| TH    | กดสั้นเพื่อเลือกช่อง Bluetooth กดค้างเพื่อยกเลิกการเชื่อมต่อ                                         |

اضغط ضغطة قصيرة لاختيار قناة البلوتوث، واضغط مطولاً للقطع.


AR




eARC OPT Bluetooth® AUX USB



or





|       |                                                             |
|-------|-------------------------------------------------------------|
| EN    | Press and hold for 5 seconds to reset.                      |
| DE    | Drücken und halten Sie 5 Sekunden lang, um zurückzusetzen.  |
| FR    | Appuyez et maintenez pendant 5 secondes pour réinitialiser. |
| ES    | Mantén presionado durante 5 segundos para restablecer.      |
| IT    | Tieni premuto per 5 secondi per ripristinare.               |
| PT    | Pressione e segure por 5 segundos para redefinir.           |
| NL/BE | Druk 5 seconden lang in om opnieuw in te stellen.           |
| PL    | Naciśnij i przytrzymaj przez 5 sekundy, aby zresetować.     |
| SV    | Håll ner i 5 sekunder för att återställa.                   |
| TR    | Sıfırlamak için 5 saniye basılı tutun.                      |
| JP    | 5秒間押し続けてリセットします。                                            |
| CN    | 按住5秒钟重置。                                                    |
| TC    | 按住5秒鐘重設。                                                    |
| KO    | 5초 동안 눌러 리셋합니다.                                             |
| ID    | Tekan dan tahan selama 5 detik untuk mengatur ulang.        |
| TH    | กดค้างไว้ 5 วินาทีเพื่อรีเซ็ต                               |

AR اضغط مع الاستمرار لمدة 5 ثوانٍ لإعادة تعيين.



<10m/33ft



|       |                                                                                                      |
|-------|------------------------------------------------------------------------------------------------------|
| EN    | On your Android™ or iOS device, connect to the soundbar via the Ultimea app.                         |
| DE    | Verbinden Sie auf Ihrem Android™- oder iOS-Gerät die Soundbar über die Ultimea-App.                  |
| FR    | Sur votre appareil Android™ ou iOS, connectez-vous à la barre de son via l'application Ultimea.      |
| ES    | En su dispositivo Android™ o iOS, conéctese a la barra de sonido a través de la aplicación Ultimea.  |
| IT    | Sul tuo dispositivo Android™ o iOS, connettiti alla soundbar tramite l'app Ultimea.                  |
| PT    | No seu dispositivo Android™ ou iOS, conecte-se à soundbar através do aplicativo Ultimea.             |
| NL/BE | Op uw Android™- of iOS-apparaat verbindt u de soundbar via de Ultimea-app.                           |
| PL    | Na swoim urządzeniu z systemem Android™ lub iOS połącz się z soundbarem za pomocą aplikacji Ultimea. |
| SV    | Anslut till soundbaren via Ultimea-appen på din Android™- eller iOS-enhet.                           |
| TR    | Android™ veya iOS cihazınızda, Ultimea uygulaması aracılığıyla soundbara bağlanın.                   |
| JP    | お使いのAndroid™またはiOSデバイスで、Ultimeaアプリを使用してサウンドバーに接続してください。                                              |
| CN    | 在您的Android™或iOS设备上，通过Ultimea应用连接到Soundbar。                                                           |
| TC    | 在您的Android™或iOS設備上，通過Ultimea應用連接到Soundbar。                                                           |
| KO    | Android™ 또는 iOS 기기에서 Ultimea 앱을 통해 사운드바에 연결하세요.                                                      |
| ID    | Pada perangkat Android™ atau iOS Anda, hubungkan ke Soundbar melalui aplikasi Ultimea.               |
| TH    | บนอุปกรณ์ Android™ หรือ iOS ของคุณ เชื่อมต่อกับ Soundbar ผ่านแอป Ultimea                             |

AR على جهاز Android™ أو iOS الخاص بك، اتصل بمكبر الصوت عبر تطبيق Ultimea.

# ULTIMEA

Product Name: Soundbar

Model No.: U2624

HVIN: U2624



Ultimea GmbH  
Buchenring 57, 22359 Hamburg, Germany



EVATOST CONSULTING LTD  
Office 101 32 Threadneedle Street, London, United Kingdom, EC2R 8AY

@Ultimea Inc. All rights reserved, registered in the United States and other countries.  
801 S. Dupont Ave., Ste G, Ontario, CA, 91761, USA

Made in China

Manufacturer: Ultimea Technology (Shenzhen) Limited

Address: 20th Floor, Building 4, Tianan Cloud Park, Bantian St., Longgang District, Shenzhen, China 518000

Manufacturer Contact Information:

+1 888-598-8875 (US)  
Mon-Fri 9am-5pm (PST)  
+49 89-628-25828 (EU)  
Mon-Fri 9am-5pm (CET)

✉ support@ultimea.com

🌐 support.ultimea.com

If you need our support, kindly reach out to our service team.  
We are always glad to help.



Download Ultimea App



Warranty Extension Plan



Search for "ULTIMEA" on social media.



**RoHS**



214-240431



Shen Zhen Shi Xin Fei Yi  
Ke Ji You Xian Gong Si



FR

Cet appareil,  
ses accessoires,  
et câbles  
se recyclent

REPRISE  
À LA LIVRAISON



OU

À DÉPOSER  
EN MAGASIN



OU

À DÉPOSER  
EN DÉCHÈTERIE



Points de collecte sur [www.uefairedemesdechets.fr](http://www.uefairedemesdechets.fr)

## General specification (English):

Model: U2624

Sound system: 7.1 channel

Power supply: 24V 3A DC(Soundbar);

14V 1A DC(Surround)

100-240V~50/60Hz AC

Drivers: 2" x 3 (Soundbar) + 2" x 4 (Surround) + 5.25"(Subwoofer)

Standby Power: <0.5W

Drivers: 2" x 3 (Soundbar) + 2" x 4 (Surround) + 5.25"(Subwoofer)

Standby Power: <0.5W

USB Output: 5V 500mA DC

Operating Temperature: -10°C-40°C/14°F-104°F

Wall Mount Screw: 4 x 32 mm / 0.2" x 1.26"

Bracket Screws Diameter: 3 mm / 0.12"

Remote Control Battery Type: 2 x AAA (NOT INCLUDED)

Notice: Risk of fire or explosion if the battery is replaced by an incorrect type.

### Dimensions

• Soundbar dimensions (W x H x D):

400 x 65 x 100 mm / 15.7" x 2.6" x 3.9"

• Subwoofer dimensions (W x H x D):

155 x 244 x 215 mm / 6.1" x 9.6" x 8.5"

• Surround dimensions (W x H x D):

82 x 88 x 81 mm / 3.2" x 3.5" x 3.2"

• Packaging dimensions (W x H x D):

330 x 439 x 190 mm / 13.0" x 17.3" x 7.5"

Packaging Weight: 6.7 kg / 14.8 lbs

### Power Consumption and Wireless Connection Setup Guide

1. Information on power consumption

This equipment complies with European COMMISSION

REGULATION (EU) 2023/826.

• Off: N/A

• Standby (when all wireless connections are deactivated): < 0.5 W

• Networked standby for Soundbar: < 2.0 W

\*The duration for the device to enter standby mode can be set in the app. Changing this setting may lead to a significant increase in energy consumption, negatively impacting the environment.

2. The period of time after which the power management function switches the equipment automatically into:

| Off               | N/A                                                                                                        |                                                                                        |
|-------------------|------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|
| Standby           | When the soundbar is idle (with no playback or operation) and neither Bluetooth® nor the app is connected. | Switched to standby mode after 15 minutes.                                             |
| Networked standby | When Bluetooth® or the app is connected.                                                                   | Switched to networked standby mode after 15 minutes of inactivity in operational mode. |

3. If this equipment has the wireless network connections:

How to activate wireless network connections:

• Set up the equipment properly;

• Switch into wireless mode (Bluetooth®);

• Connect with energy using products (e.g. players/ game consoles/ STB (Set-Top Boxes)/ phones/ tablets/ PCs). How to deactivate wireless network connections:

• Switch to another channel besides Bluetooth®;

• Then long press  on the remote control for more than 3 seconds.

For other languages of the above content

(DE, FR, ES, IT, PT, NL, PL, SV, TR, JP, CN, TC, KO, ID, TH, AR), please scan the QR code



## IMPORTANT SAFETY INSTRUCTIONS (English):

1. Please read and retain this manual. Follow all warnings and operate according to the instructions.

2. Do not use the device near water sources, in damp environments, or in the rain. Avoid splashing liquids or placing objects containing liquids (such as vases) on the device.

3. Clean only with a dry cloth. Do not use liquid cleaners.

4. Do not block ventilation openings or install the device in an enclosed space. Ensure proper ventilation and install according to the manufacturer's instructions.

5. Do not install the device near heat sources such as radiators, stoves, or amplifiers. Do not cover the ventilation openings with items such as newspapers or curtains.

6. Use only attachments, stands, or accessories specified by the manufacturer. When using a device with wheels, move with care to avoid tipping.

7. Protect the power cord from being pinched, stepped on, or bent, especially at plugs, outlets, and the point where it exits the device.

8. Do not alter the polarized or grounding-type plug. If the plug does not fit into the outlet, consult an electrician to replace the outlet.

9. Unplug the device during lightning storms or when unused for long periods. To fully disconnect power, unplug the device from the wall outlet and ensure the plug is accessible.

10. Do not place any open flame sources (such as lit candles) on or near the device.

11. Do not attempt to open the device. High voltage inside may be fatal.

There are no user-serviceable parts inside. All servicing must be performed by qualified personnel.

12. The installation height of the device must not exceed 2 meters.



Scan QR for safety info / QR-Code für Infos scannen / Scanner le QR pour info / Escanee QR para info / Scansione il QR per info / Leia o QR para info / Scan QR-code voor info / Zeskanuj kod QR / Skanna QR for info / QR kodu tara / QRコードを読み取らせ / 扫码查看安全信息 / 掃描查看安全資訊 / QR 코드 가져 / Pindai QR untuk informasi keselamatan / Aunni QR 掃碼  
تعليمات السلامة / تعليمات السلامة / تعليمات السلامة

## PROPER DISPOSAL INSTRUCTIONS



This mark shown on the product or its packaging, indicates that this product should not be disposed of with other household waste at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

## Waste Electrical & Electronic Equipment

Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

## WIRELESS FREQUENCY RANGE AND WIRELESS OUTPUT POWER:

Frequency: 2.402GHz-2.48GHz

The Max. transmit power (Applies only to the EU): 10 dBm

## FCC REGULATORY COMPLIANCE

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## ISED WARNINGS

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux

CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- 3) The device meets the exemption from the routine evaluation limits in issue6 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la numéro 6 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. Cet émetteur ne doit pas être Co-placé ou ne fonctionner en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

## Wireless Capability Description:

The right rear surround is equipped with a wireless signal reception module, enabling it to receive audio signals from the main device for playback. This device only supports wireless signal reception and cannot relay or forward signals. The subwoofer in the system is designed for wired connection and does not have the ability to transmit or receive wireless signals.

The remote control uses infrared (IR) technology for device control and does not support any other wireless signal transmission or reception capabilities.

**⚠ CA WARNING:** Can expose you to BPA, a carcinogen, and BPA, a reproductive, toxicant. See [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## CE WARNINGS

- 1) Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
- 2) WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
- 3) WARNING: The adapter plug is used as disconnect device, the disconnect device shall remain readily operable.
- 4) Frequency: 2.402GHz-2.48GHz
- 5) The Max. transmit power: 10 dBm

## EU Declaration of Conformity

We (Manufacturer is responsible for this declaration)  
Ultimea Technology (Shenzhen) Limited  
(Company name)

20th Floor, Building 4, Tianan Cloud Park, Bantian St.,  
Longgang District Shenzhen, China 518000  
(Company address)

Declare under our sole responsibility that the product  
Trade Mark: ULTIMEA  
Product Name: Soundbar  
Model No.: U2624

The product to which this declaration relates is in conformity with the essential requirements set out in the Council Directive on the Approximation of the laws of the Member States relating to the Radio Equipment Directive (2014/53/EU), the Restriction of Hazardous Substances Directive (2011/65/EU), the Electromagnetic Compatibility Directive (2014/30/EU), and the Low Voltage Directive (2014/35/EU). The product is responsible for affixing the CE marking, and the following standards were applied:

EN 55032:2015/A1:2020

EN 55035:2017/A1:2020

EN IEC 61000-3-2:2019/A1:2021

EN 61000-3-3:2013/A2:2021

ETSI EN 301 489-1 V2.2.3 (2019-11)

ETSI EN 301 489-17 V3.2.4 (2024-09)

ETSI EN 300 328 V2.2.2 (2019-07)

EN 50663: 2017

EN IEC 62368-1:2020+A1:2020

IEC 62321-3-1:2013

IEC 62321-4:2013+A1:2017

IEC 62321-5:2013

IEC 62321-6:2015


IEC 62321-7-1:2015

IEC 62321-7-2:2017

IEC 62321-8:2017

Full Name: Yoyo.Yu

Position: Approbation Manager

Signature: 

Place/Date: Shenzhen, China / Apr. 01-2026

## Trade Marks:



Dolby, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012–2024 Dolby Laboratories. All rights reserved.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Ultimea Technology (Shenzhen) Limited. is under license. Other trademarks and trade names are those of their respective owners.



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



**EN** Normally, the Soundbar and Surround are pre-paired. If disconnected, follow the steps below. The Surround indicator will stay solid when paired successfully.

**DE** Normalerweise sind die Soundbar und die Surround-Lautsprecher vorab gekoppelt. Bei einer Trennung folgen Sie den untenstehenden Anweisungen. Die Surround-Anzeige leuchtet konstant, wenn die Verbindung erfolgreich ist.

**FR** Normalement, la barre de son et les enceintes surround sont déjà appairées. En cas de déconnexion, suivez les instructions ci-dessous. Le voyant des enceintes surround restera fixe une fois l'appairage réussi.

**ES** Normalmente, la barra de sonido y los altavoces surround están emparejados previamente. Si se desconectan, siga los pasos a continuación. El indicador de los altavoces surround permanecerá encendido cuando se haya emparejado con éxito.

**IT** Normalmente, la soundbar e gli altoparlanti surround sono pre-acoppiati. In caso di disconnessione, seguire i passaggi seguenti. L'indicatore degli altoparlanti surround rimarrà acceso una volta completato l'abbinamento.

**PT** Normalmente, a barra de som e os alto-falantes surround são pré-emparelhados. Caso estejam desligados, siga os passos abaixo. O indicador dos alto-falantes surround permanecerá sólido quando o emparelhamento for bem-sucedido.

**NL/BE** Normaal gesproken zijn de soundbar en surround-luidsprekers vooraf gekoppeld. Indien losgekoppeld, volg de onderstaande stappen. Het lampje op de surround-luidsprekers blijft branden wanneer het succesvol is gekoppeld.

**PL** Zazwyczaj soundbar i głośniki surround są wstępnie sparowane. W przypadku rozłączenia, wykonaj poniższe kroki. Wskaźnik na głośnikach surround będzie stale świecić po udanym sparowaniu.

**SV** Vanligtvis är soundbaren och surround-högtalarna förkopplade. Om de kopplas bort, följ stegen nedan. Indikatorlampan på surround-högtalarna kommer att lysa fast när de har anslutits framgångsrikt.

**TR** Normalde, Soundbar ve Surround hoparlörler önceden eşleştirilmiştir. Ayrılma durumunda aşağıdaki adımları izleyin. Surround hoparlörlerin göstergesi eşleştirme başarılı olduğunda sabit yanar.

**JP** 通常、サウンドバーとサラウンドスピーカーは事前にペアリングされています。切断された場合、以下の手順に従ってください。サラウンドスピーカーのインジケータが点灯するとペアリングが成功です。

**CN** 通常，Soundbar 和环绕音箱已提前配好。如果断开了连接，请按照以下步骤操作。配对成功后，环绕音箱指示灯将保持常亮。

**TC** 通常，Soundbar 和環繞音箱已提前配好。如果斷開了連接，請按照以下步驟操作。配對成功後，環繞音箱指示燈將保持常亮。

**KO** 일반적으로 사운드바와 서라운드 스피커는 미리 페어링되어 있습니다. 연결이 끊어질 경우 아래 단계를 따르세요. 페어링이 성공하면 서라운드 스피커의 표시등이 계속 켜져 있습니다.

**ID** Secara umum, soundbar dan speaker surround sudah dipasangkan sebelumnya. Jika koneksi terputus, ikuti langkah-langkah berikut. Setelah pemasangan berhasil, indikator speaker surround akan tetap menyala.

**TH** โดยปกติแล้ว Soundbar และลำโพงรอบทิศทางจะถูกจับคู่อย่างเรียบร้อยแล้ว หากการเชื่อมต่อถูกตัดออก โปรดทำตามขั้นตอนต่อไป หลังจากจับคู่สำเร็จ โฉแสดงสถานะของลำโพงรอบทิศทางจะสว่างคงที่

**AR** بشكل افتراضي، يتم اقتران مكبر الصوت ومضخم الصوت مسبقاً. في حالة قطع الاتصال، اتبع التعليمات التالية: سيظل ضوء المؤشر على مضخم الصوت ثابتاً عند اكتمال الاقتران بنجاح.

