ULTIMEA

Dolby Atmos

HDMI
HIGH-DEFINITION MULTIMEDIA INTERFACE

Bluetooth®




Buku Panduan


Poseidon D60

Nomor Model: U2520
Soundbar Dolby Atmos 5.1


- 1.Bacalah dan simpan petunjuk ini. Ikuti semua peringatan dan operasikan sesuai dengan petunjuk.
- 2.Jangan gunakan perangkat di dekat air, di lingkungan lembap, atau di tengah hujan. Hindari menumpahkan cairan ke perangkat atau menempatkan benda berisi cairan (seperti vas) di atasnya.
- 3.Bersihkan hanya dengan kain kering. Jangan gunakan pembersih cair.
- 4.Jangan menghalangi bukaan ventilasi atau memasang perangkat di ruang tertutup. Pastikan ventilasi yang memadai dan pasang perangkat sesuai dengan petunjuk pabrikan.
- 5.Jangan memasang perangkat di dekat sumber panas seperti radiator, kompor, amplifier, atau perangkat lain yang menghasilkan panas. Jangan menutupi bukaan ventilasi dengan barang seperti koran atau tirai.
- 6.Hanya gunakan lampiran, dudukan, atau aksesori yang ditentukan oleh pabrikan. Saat menggunakan peralatan dengan roda, berha-ti-hatilah saat memindahkan untuk mencegah terguling.
- 7.Lindungi kabel daya dari terinjak, terjepit, atau tertekuk, terutama di steker, stopkontak, dan titik keluar dari perangkat.
- 8.Jangan mengubah polarisasi atau fitur pembumian steker. Jika steker tidak cocok dengan stopkontak, konsultasikan dengan teknisi listrik untuk mengganti stopkontak.
- 9.Cabut kabel daya selama badai petir atau saat tidak digunakan dalam waktu lama.
- 10.Jangan menempatkan sumber api terbuka, seperti lilin menyala, di atas perangkat.
- 11.Jangan mencoba membuka perangkat. Tegangan tinggi di dalam dapat menyebabkan sengatan listrik atau kematian. Semua perbaikan harus dilakukan oleh personel yang berkualifikasi.
- 12.Ketinggian pemasangan perangkat tidak boleh melebihi 2 meter.

2 DAFTAR AKSESORI







Adaptor daya soundbar(2m/78")




Kabel daya subwoofer(2m/78")



Kabel koneksi surround(6m/236")




Kabel HDMI(1.5m/59")




Kabel optik digital(1.5m/59")




Pengendali jarak jauh



Sekrup braket




Braket dinding



Pasak ekspansi dinding

3 KONTROL SOUNDBAR



PANEL KONTROL

1. **“⏻”: Tombol Daya**
   Tekan untuk menghidupkan / mematikan.

2. **“⏏”: Sumber**
   Tekan untuk berpindah: eARC - OPT(OPTICAL) - Bluetooth® - AUX - USB.


3. **“ᛒ”: Bluetooth®**
   Tekan untuk mode Bluetooth®, pairing otomatis.
   Tahan 3 dtk untuk pairing ulang. (ID: Poseidon D60)

4. **“−”: Volume –**

5. **“+”: Volume +**


4 REMOTE CONTROL

1. “⏻” : **Tombol daya**
   Tekan untuk menghidupkan / mematikan.
2. “▭”: **eARC**
   Tekan untuk beralih ke saluran HDMI eARC.
3. “⇥”: **SOURCE**
   Tekan untuk mengganti saluran.
4. “▣”: **OPT**
   Tekan untuk beralih ke saluran OPTICAL.
5. “◎”: **AUX**
   Tekan untuk beralih ke saluran AUX.
6. “ᛒ”: **Bluetooth®**
   Tekan untuk beralih ke Bluetooth®.
7. “▭”: **USB**
   Tekan untuk beralih ke saluran USB.
8. “▣”: **SUB PAIR**
   Tekan dan tahan tombol selama 3 detik untuk membuat Soundbar dalam keadaan siap dipasangkan dengan subwoofer.
9. “ᛪ”: **XUPMIX**
   Pengaturan default adalah "on", yang memungkinkan kontrol terpadu atas aktivasi dan penonaktifan 6 mode efek suara.
   Xupmix on: Suara saluran surround akan disediakan oleh sinyal multi-saluran kaya yang diproses oleh algoritme, menawarkan pengalaman pendengaran yang lebih imersif.
   Xupmix off: Suara saluran surround akan dioptimalkan berdasarkan sinyal saluran kiri dan kanan menggunakan algoritme, menghasilkan efek bidang suara yang lebih luas.
10. “＋”: **Volume naik**
11. “—”: **Volume turun**
12. “<”: **Sebelumnya**
    Hanya BLUETOOTH® & USB: trek sebelumnya.
13. “>”: **Berikutnya**
    Hanya BLUETOOTH® & USB: trek berikutnya.
14. “⏯”: **Putar / Jeda**
    Hanya BLUETOOTH® & USB.
15. “🔇”: **MUTE**
    Bisu. Tekan dan tahan selama 5 detik untuk mengatur ulang.
16. “💡”: **LED DIMMER**
    Tekan untuk menyesuaikan kecerahan layar dalam 5 tingkat.
    Tekan dan tahan selama 3 detik untuk mematikan layar.
17. “BASS ᛪ”: **BASSMX**
    Tekan untuk atur bass.
18. “MIDRANGE”: **MIDRANGE**
    Tekan untuk menyesuaikan tingkat frekuensi menengah.
19. “TREBLE”: **TREBLE**
    Tekan untuk menyesuaikan tingkat treble.
20. “🎥”: **MOVIE**
    Tekan untuk beralih ke mode FILM, layar akan menampilkan: “ E91 ”.
21. “♫”: **MUSIC**
    Tekan untuk beralih ke mode MUSIK, layar akan menampilkan: “ E92 ”.
22. “▁▂▃▂▁”: **VOICE**
    Tekan untuk beralih ke mode SUARA, layar akan menampilkan: “ E93 ”.
23. “🏃”: **SPORT**
    Tekan untuk beralih ke mode OLAHRAGA, layar akan menampilkan: “ E94 ”.
24. “🎮”: **GAME**
    Tekan untuk beralih ke mode GAME, layar akan menampilkan: “ E95 ”.
25. “☾”: **NIGHT**
    Tekan untuk beralih ke mode MALAM, layar akan menampilkan: “ E96 ”.




26. “SURROUND”: **SURROUND**
    Tekan untuk menyesuaikan tingkat suara surround.
27. “PROMPT TONE”: **PROMPT TONE**
    Tekan untuk menyesuaikan level nada konfirmasi, layar akan menampilkan: “PE 0”, “PE 1”, “PE 2”, “PE 3”

5 KONEKSI PANEL BELAKANG




1. **DC IN**
2. **AUX**
3. **OPTICAL**
4. **USB (MENDUKUNG MP3 ATAU FLAC)**
5. **HDMI TO TV(EARC)**

6 PENEMPATAN SISTEM



Catatan: Pasang setinggi telinga.


7 PEMASANGAN DINDING




Catatan: Braket dinding yang digunakan untuk speaker surround identik dengan yang digunakan untuk speaker utama, jadi jarak lubang vertikalnya sama dengan soundbar, dan metode pemasangannya juga sama.

8 HUBUNGKAN & NYALAKAN

1 Sambungkan soundbar ke sumber daya listrik.




2 Sambungkan subwoofer ke sumber daya listrik.




3 Hubungkan subwoofer dan speaker surround menggunakan kabel speaker surround.

Speaker satelit surround di sisi kanan akan memiliki antarmuka merah, sedangkan speaker satelit surround di sisi kiri akan memiliki antarmuka putih.




4 Masukkan baterai ke remote.

Catatan: Gunakan baterai alkaline. Baterai isi ulang tidak disarankan.




9 HUBUNGKAN TV VIA HDMI eARC

1. Sambungkan satu ujung kabel HDMI ke port eARC/ARC TV.
2. Sambungkan ujung lainnya ke port eARC soundbar.



3. Tekan tombol "Source" pada Soundbar atau remote control untuk memilih input "eARC".



Catatan: Pastikan port HDMI TV Anda mendukung eARC; jika tidak, sinyal audio Dolby Atmos tidak dapat ditransmisikan.

Dolby Atmos: Jika Anda menonton konten dalam format Dolby Atmos, atur output audio TV Anda ke «Pass Through».
Pengaturan TV > Beranda > Pengaturan > Suara > Output Audio Digital > Pass Through


HDMI eARC (Enhanced Audio Return Channel) adalah versi upgrade dari ARC yang mendukung format audio berkualitas lebih tinggi seperti Dolby Atmos.

Catatan: Aktifkan fungsi “CEC” pada TV Anda. Saat eARC terhubung, remote TV Anda dapat mengontrol Soundbar dan TV secara bersamaan:

(1) Nyalakan / Siaga
(2) Sesuaikan Volume


10 HUBUNGKAN TV VIA KABEL OPTIK

1. Pastikan TV Anda memiliki port OPTICAL OUT. Gunakan kabel optik untuk menghubungkan port OPTICAL OUT pada TV ke port OPTICAL IN pada soundbar.



2. Pastikan konektor kabel optik terpasang dengan benar seperti yang ditunjukkan pada gambar. Jangan memasukkan konektor secara terbalik karena dapat merusak port optik.


3. Pengaturan TV > Home > Sound > Digital Audio Output > PCM



Catatan: Jika audio diputar melalui speaker internal TV, bisukan TV atau turunkan volume ke minimum.


Port optik tidak mendukung Dolby Atmos. Untuk pengalaman Dolby Atmos terbaik, gunakan HDMI eARC.

11 HUBUNGKAN BLUETOOTH®



1. Tekan tombol " " pada soundbar atau remote untuk masuk mode pairing Bluetooth®.
2. Buka pengaturan Bluetooth di ponsel Anda, cari dan pilih "Poseidon D60" untuk menghubungkan ponsel ke soundbar.
3. Catatan: Jika soundbar sudah berada dalam mode Bluetooth dan terhubung ke perangkat, tekan dan tahan tombol " " selama 3 detik untuk memutuskan koneksi perangkat saat ini. Kemudian, pilih soundbar secara manual di ponsel, PC, atau TV Anda untuk membuat koneksi Bluetooth baru.

12 PASANGKAN ULANG SUBWOOFER




Biasanya soundbar dan subwoofer telah dipasangkan.
Jika koneksi terputus, ikuti langkah berikut.

1. Tekan dan tahan tombol "SUB PAIR" selama 3 detik.
   Layar menampilkan " SUB " berkedip menandakan mode pairing.
2. Tekan dan tahan tombol pairing di belakang subwoofer selama 5 detik.
3. Setelah pairing berhasil, tampilan berhenti berkedip dan lampu indikator menyala tetap.

13 KEMBALIKAN PENGATURAN PABRIK

Tekan dan tahan tombol MUTE selama 5 detik untuk mengembalikan pengaturan pabrik.




14 ATUR VOLUME SUARA PETUNJUK


Download Ultimea App

Available on the App Store

GET IT ON Google Play

ULTIMEA





Jika suara petunjuk terlalu keras, atur melalui aplikasi ULTIMEA.

1. Pindai kode QR untuk mengunduh aplikasi ULTIMEA lalu tambahkan soundbar.
2. Buka detail perangkat, ketuk Pengaturan dan pilih “Prompt Sound ” untuk menyesuaikan.

15 SPESIFIKASI TEKNIS

Model Number	U2520
Power Supply	DC 18V 3A (Soundbar) / AC 100~240V (Subwoofer)
Soundbar Drivers	Soundbar: 2.25" × 3, Surround: 2.25" × 2, Subwoofer: 5.25"
Auto Standby	The soundbar will turn to standby mode if there is no audio signal for 15 minutes. You can set the standby time in the App
Standby Power	<0.5W
Operating Temperature	-10°C – 40°C / 14°F – 104°F
Bluetooth® Version	5.3

Soundbar	400 x 70x 90 mm/15.7" x 2.8" x 3.5"
Subwoofer	155x244x215mm/6.1"x9.6"×8.5"
Surround	135x70x90mm/5.3"x2.8"x3.5"
Packaging	328x440x190mm/12.9"×17.3" x 7.5"
Packaging Weight	6.35 kg /14 lbs

USB Output	5V 500mA
Operating Altitude	2000 meters above sea level
Wall Mount Screw	4 × 32 mm / 0.16" × 1.26"
Bracket Screws Diameter	3 mm / 0.12"
Remote Control Battery Type	2 × AAA (NOT INCLUDED)
Notice: Risk of fire or explosion if the battery is replaced by an incorrect type.	

PROPER DISPOSAL INSTRUCTIONS



This mark shown on the product or its packaging, indicates that this product should not be disposed of with other household waste at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

For indoor use only



This symbol indicates that the product is intended for indoor use only.

Class II equipment



This symbol indicates that the product is Class II equipment.

Waste Electrical & Electronic Equipment

Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

WIRELESS FREQUENCY RANGE AND WIRELESS OUTPUT POWER:

Frequency: 2.402GHz-2.48GHz
The Max. transmit power (Applies only to the EU): 10 dBm

FCC REGULATORY COMPLIANCE

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED WARNINGS

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux
CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes :
1) L'appareil ne doit pas produire de brouillage;
2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
3) The device meets the exemption from the routine evaluation limits in issue6 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.
Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la numéro 6 de RSS 102 etla conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne surl'exposition et la conformité de rf.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.
Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ouémetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

Wireless Capability Description:

The subwoofer is equipped with a wireless signal reception module, enabling it to receive audio signals from the main device for playback. This device only supports wireless signal reception and cannot relay or forward signals.
The two surround speakers in the system are designed for wired connection and do not have the ability to transmit or receive wireless signals.
The remote control uses infrared (IR) technology for device control and does not support any other wireless signal transmission or reception capabilities.

⚠ **CA WARNING:** Can expose you to BPA, a carcinogen, and BPA, a reproductive. toxicant. See www.P65Warnings.ca.gov.

CE WARNINGS

1) Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
2) WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
3) WARNING: The adapter plug is used as disconnect device, the disconnect device shall remain readily operable.
4) Frequency: 2.402GHz-2.48GHz
5) The Max. transmit power: 10 dBm

EU Declaration of Conformity

We (Manufacturer is responsible for this declaration)
Ultimea Technology (Shenzhen) Limited
(Company name)

9th Floor, Building A, Shenzhen Industrial Software Park, Bantian Street, Longgang District, Shenzhen, China 518000
(Company address)

Declare under our sole responsibility that the product
Trade Mark: ULTIMEA
Product Name: Poseidon D60 5.1 Channel Dolby Atmos Soundbar
Model No.: U2520

The product to which this declaration relates is in conformity with the essential requirements set out in the Council Directive on the Approximation of the laws of the Member States relating to the Radio Equipment Directive (2014/53/EU), the Restriction of Hazardous Substances Directive (2011/65/EU), the Electromagnetic Compatibility Directive (2014/30/EU), and the Low Voltage Directive (2014/35/EU). The product is responsible for affixing the CE marking, and the following standards were applied:

EN 55032:2015/A1:2020
EN 55035:2017/A11:2020
EN IEC 61000-3-2:2019/A1:2021
EN 61000-3-3:2013/A2:2021
ETSI EN 301 489-1 V2.2.3 (2019-11)
ETSI EN 301 489-17 V3.3.1 (2024-09)
ETSI EN 300 328 V2.2.2 (2019-07)
EN 50663: 2017
EN IEC 62368-1:2020+A11:2020
IEC 62321-3-1:2013
IEC 62321-4:2013+A1:2017
IEC 62321-5:2013
IEC 62321-6:2015
IEC 62321-7-1:2015
IEC 62321-7-2:2017
IEC 62321-8:2017

Full Name: Yoyo.Yu
Position: Approbation Manager

Signature: yoyo yu

Place/Date: Shenzhen, China / Sep. 13-2024

Trade Marks:

Dolby, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012–2024 Dolby Laboratories. All rights reserved.

HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by Ultimea Technology (Shenzhen) Limited. is under license. Other trademarks and trade names are those of their respective owners.

General specification (English):

Model: U2520
Sound system: 5.1 channel
Power supply: 18V 3A DC(Soundbar);
100-240V~50/60Hz AC (Subwoofer)
Drivers: 2.25"×3(Soundbar) + 2.25"×2 (Surround)
+5.25"(Subwoofer)
Standby Power: <0.5W
USB Output: 5V 500mA DC
Operating Temperature: -10°C-40°C/14°F-104°F
Operating Altitude: 2000 meters above sea level
Wall Mount Screw: 4 × 32 mm / 0.16" × 1.26"
Bracket Screws Diameter: 3 mm / 0.12"
Remote Control Battery Type: 2 x AAA (NOT INCLUDED)
Notice: Risk of fire or explosion if the battery is replaced by an incorrect type.

Dimensions

・Soundbar dimensions (W x H x D):
400 x 70 x 90 mm / 15.7" x 2.8" x 3.5"
・Subwoofer dimensions (W x H x D):
155 x 244 x 215 mm / 6.1" x 9.6" x 8.5"
・Surround dimensions (W x H x D):
135 x 70 x 90 mm / 5.3" x 2.8" x 3.5"
・Packaging dimensions (W x H x D):
328 x 440 x 190 mm / 12.9" x 17.3" x 7.5"
・Packaging Weight: 6.35 kg / 14 lbs

Power Consumption and Wireless Connection Setup Guide

1. Information on power consumption
This equipment complies with European COMMISSION REGULATION (EU) 2023/826.
• Off: N/A
• Standby (when all wireless connections are deactivated): < 0.5 W
• Networked standby for Soundbar: < 2.0 W
*The duration for the device to enter standby mode can be set in the app. Changing this setting may lead to a significant increase in energy consumption, negatively impacting the environment.
2. The period of time after which the power management function switches the equipment automatically into:

Off	N/A	
Standby	When the soundbar is idle (with no playback or operation) and neither Bluetooth®nor the app is connected.	Switched to standby mode after 15 minutes.
Networked standby	When Bluetooth® or the app is connected.	Switched to networked standby mode after 15 minutes of inactivity in operational mode.

3. If this equipment has the wireless network connections:
How to activate wireless network connections:
• Set up the equipment properly;
• Switch into wireless mode (Bluetooth®);
• Connect with energy using products (e.g. players/ game consoles/ STB (Set-Top Boxes)/ phones/ tablets /PCs). How to deactivate wireless network connections: • Switch to another channel besides Bluetooth®;
• Then long press on the remote control for more than 3 seconds.

For other languages of the above content
(DE, FR, ES, IT, PT, NL, PL, SV, TR, JP, CN, TC, KO, ID, TH, AR),
please scan the QR code

IMPORTANT SAFETY INSTRUCTIONS (English):

1.Please read and retain this manual. Follow all warnings and operate according to the instructions.
2.Do not use the device near water sources, in damp environments, or in the rain. Avoid splashing liquids or placing objects containing liquids (such as vases) on the device.
3.Clean only with a dry cloth. Do not use liquid cleaners.
4.Do not block ventilation openings or install the device in an enclosed space. Ensure proper ventilation and install according to the manufacturer's instructions.
5.Do not install the device near heat sources such as radiators, stoves, or amplifiers. Do not cover the ventilation openings with items such as newspapers or curtains.
6.Use only attachments, stands, or accessories specified by the manufacturer. When using a device with wheels, move with care to avoid tipping.
7.Protect the power cord from being pinched, stepped on, or bent, especially at plugs, outlets, and the point where it exits the device.
8.Do not alter the polarized or grounding-type plug. If the plug does not fit into the outlet, consult an electrician to replace the outlet.
9.Unplug the device during lightning storms or when unused for long periods. To fully disconnect power, unplug the device from the wall outlet and ensure the plug is accessible.
10.Do not place any open flame sources (such as lit candles) on or near the device.
11.Do not attempt to open the device. High voltage inside may be fatal. There are no user-serviceable parts inside. All servicing must be performed by qualified personnel.
12.The installation height of the device must not exceed 2 meters.

Scan QR for safety info / QR-Code für Infos scannen / Scanner le QR pour infos / Escanee QR para info / Scansiona il QR per info / Leia o QR para info / Scan QR-code voor info / Zeskanuj kod QR / Skanna QR för info / QR kodu tara / QRコードをスキャン / 扫码查看安全信息 / 掃碼查看安全資訊 / QR 코드 스캔 / Pindai QR untuk informasi keselamatan / สแกน QR เพื่อดูข้อมูลความปลอดภัย / امسح رمز QR لمعلومات السلامة

ULTIMEA

Product Name: Poseidon D60 5.1 Channel Dolby Atmos Soundbar
Model No.: U2520
HVIN: U2520S3

EC REP
Ultimea GmbH
Buchenring 57, 22359 Hamburg, Germany

UK REP
EVATOST CONSULTING LTD
Office 101 32 Threadneedle Street, London,
United Kingdom, EC2R 8AY

© Ultimea Inc. All rights reserved, registered in the United States and other countries.
801 S. Dupont Ave., Ste G, Ontario, CA, 91761, USA

Made in China
Manufacturer: Ultimea Technology (Shenzhen) Limited
Address: 9th Floor, Building A, Shenzhen Industrial Software Park, Bantian Street, Longgang District, Shenzhen, China 518000

Manufacturer Contact Information:

+1 888-598-8875 (US)
Mon-Fri 9am-5pm (PST)

+49 89-628-25828 (EU)
Mon-Fri 9am-5pm (CET)

support@ultimea.com

support.ultimea.com

If you need our support, kindly reach out to our service team.
We are always glad to help.

Download Ultimea App

GET IT ON Google Play

Available on the App Store

ULTIMEA

Search for “ULTIMEA” on social media.

RoHS

R 214-240436

FR Cet appareil, ses accessoires, et cordons se recyclent
REPRISE À LA LIVRAISON ou À DÉPOSER EN MAGASIN ou À DÉPOSER EN DÉCHÈTERIE
Points de collecte sur www.uefairedemesdechets.fr

Warranty Extension Plan

Regardless of where you purchased your Ultimea product,
you can easily opt for this extended warranty.
Scan to check out our extended warranty options.