ULTIMEA



Användarmanual


Poseidon D60


Modellnr: U2520
5.1 Dolby Atmos-soundbar

1 VIKTIGA SÄKERHETSANVISNINGAR


- 1.Läs och spara dessa instruktioner. Följ alla varningar och använd enheten enligt instruktionerna.
- 2.Använd inte enheten nära vatten, i fuktiga miljöer eller i regn. Undvik att spilla vätskor på enheten eller placera föremål som innehåller vätskor (t.ex. vaser) ovanpå den.
- 3.Rengör endast med en torr trasa. Använd inte flytande rengöringsmedel.
- 4.Blockera inte ventilationsöppningar och installera inte enheten i ett slutet utrymme. Se till att det finns tillräcklig ventilation och installera enheten enligt tillverkarens instruktioner.
- 5.Installera inte enheten nära värmekällor som element, spisar, förstärkare eller andra apparater som avger värme. Täck inte över ventilationsöppningarna med tidningar eller gardiner.
- 6.Använd endast tillbehör, stativ eller fästen som specificerats av tillverkaren. Var försiktig när du flyttar utrustning med hjul för att förhindra att den välter.
- 7.Skydda nätkabeln från att trampas på, klämmas eller böjas, särskilt vid kontakter, uttag och där den lämnar enheten.
- 8.Ändra inte kontaktdonets polarisering eller jordningsegenskaper. Om kontakten inte passar i uttaget, kontakta en elektriker för att byta uttaget.
- 9.Dra ut nätkabeln under åskväder eller när den inte används under längre perioder.
- 10.Placera inga öppna lågor, såsom tända ljus, på enheten.
- 11.Försök inte öppna enheten. Hög spänning inuti kan orsaka elchock eller dödsfall. All service måste utföras av kvalificerad personal.
- 12.Installationshöjden för enheten får inte överstiga 2 meter.

2 TILLBEHÖRSLISTA







Soundbar-nätadapter(2m/78")




Subwoofer-strömkabel(2m/78")



Surround-anslutningskabel (6m/236")




HDMI-kabel (1.5m/59")




Digital optisk kabel(1.5m/59")




Fjärrkontroll



Monteringsskruv




Väggfäste



Väggplugg

3 SOUNDBAR-KONTROLLER



KONTROLLPANEL

❶ **"⏻": Strömknapp**
Tryck för att slå på/stänga av.

❷ **"⏏": Källa**
Tryck för att växla: eARC - OPT(OPTICAL) - Bluetooth® - AUX - USB.


❸ **"ᛒ": Bluetooth®**
Tryck för Bluetooth®-läge, automatisk parkoppling.
Håll in 3 s för ny parkoppling. (ID: Poseidon D60)

❹ **"−": Volym −**

❺ **"+": Volym +**


4 FJÄRRKONTROLL

1. “⏻” : **Strömknapp**
   Tryck för att slå på/stänga av.
2. “▭”: **eARC**
   Tryck för att växla till HDMI eARC-kanalen.
3. “⇥”: **SOURCE**
   Tryck för att växla mellan ingångskällorna.
4. “▣”: **OPT**
   Tryck för att växla till OPTISK kanal.
5. “◎”: **AUX**
   Tryck för att växla till AUX-kanalen.
6. “ᛒ”: **Bluetooth®**
   Tryck för att växla till Bluetooth®.
7. “▭”: **USB**
   Tryck för att växla till USB-kanalen.
8. “▣”: **SUB PAIR**
   Tryck och håll in knappen i 3 sekunder för att sätta Soundbaren i ett tillstånd redo att para ihop med subwoofern.
9. “ᛪ”: **XUPMIX**
   Standardinställningen är "on", vilket möjliggör enhetlig kontroll över aktivering och inaktivering av de 6 ljudeffektlägena.
   Xupmix on: Ljudet från surroundkanalen kommer att tillhandahållas av en rik flerkanalssignal som bearbetas av algoritmen, vilket ger en mer uppslukande lyssningsupplevelse.
   Xupmix off: Ljudet från surroundkanalen kommer att optimeras baserat på vänster- och högerkanalssignalerna med hjälp av en algoritm, vilket resulterar i en bredare ljudfältseffekt.
10. “＋”: **Volym upp**
11. “—”: **Volym ner**
12. “<”: **Föregående**
    Endast BLUETOOTH® och USB: föregående spår.
13. “>”: **Nästa**
    Endast BLUETOOTH® och USB: nästa spår.
14. “⏯”: **Spela / Pausa**
    Endast BLUETOOTH® och USB.
15. “🔇”: **MUTE**
    Tysta. Tryck och håll i 5 sekunder för att återställa.
16. “💡”: **LED DIMMER**
    Tryck för att justera displayens ljusstyrka i 5 nivåer. Tryck och håll in i 3 sekunder för att stänga av displayen.
17. “BASS ᛪ”: **BASSMX**
    Tryck för att justera basen.
18. “MIDRANGE”: **MIDRANGE**
    Tryck för att justera nivån för mellanregistret.
19. “TREBLE”: **TREBLE**
    Tryck för att justera diskantnivån.
20. “🎬”: **MOVIE**
    Tryck för att växla till FILM-läge, displayen visar: " E91 ".
21. “♫”: **MUSIC**
    Tryck för att växla till MUSIK-läge, displayen visar: " E92 ".
22. “🎙”: **VOICE**
    Tryck för att växla till RÖST-läge, displayen visar: " E93 ".
23. “🏃”: **SPORT**
    Tryck för att växla till SPORT-läge, displayen visar: " E94 ".
24. “🎮”: **GAME**
    Tryck för att växla till SPEL-läge, displayen visar: " E95 ".
25. “🌙”: **NIGHT**
    Tryck för att växla till NATT-läge, displayen visar: " E96 ".




26. “SURROUND”: **SURROUND**
    Tryck för att justera surroundljudnivån.
27. “PROMPT TONE”: **PROMPT TONE**
    Tryck för att justera nivån på meddelandetonen, displayen visar: “Pt 0”, “Pt 1”, “Pt 2”, “Pt 3”.

5 ANSLUTNINGAR PÅ BAKPANELEN




1. **DC IN**
2. **AUX**
3. **OPTICAL**
4. **USB (Stöder MP3 eller FLAC)**
5. **HDMI to TV(eARC)**

6 SYSTEMPLACERING



Obs: Placera soundbaren i öronhöjd.


7 VÄGGMONTERING




Obs! Väggfästet som används för surroundhögtalarna är identiskt med det för ljudhögtalaren, så det vertikala hålavståndet är detsamma som för soundbaren och installationsmetoden är också densamma.

8 ANSLUT OCH STARTA

1 Anslut soundbaren till strömförsörjningen.




2 Anslut subwoofern till strömförsörjningen.




3 Anslut subwoofern och surroundhögtalarna med surroundhögtalarkabeln.

Surround-satellithögtalarna på höger sida har röda gränssnitt, medan surround-satellithögtalarna på vänster sida har vita gränssnitt.



4 Sätt i batterierna.


Obs: Alkaliska batterier rekommenderas. Uppladdningsbara batterier avråds.




9. ANSLUT TV VIA HDMI eARC

1. Anslut ena änden av HDMI-kabeln till TV:ns eARC/ARC-port.

2. Anslut den andra änden till soundbarens eARC-port.



3. Tryck på "Source"-knappen på soundbaren eller fjärrkontrollen för att välja "eARC"-ingången.



Obs! Se till att din TV:s HDMI-port stöder eARC; annars kan Dolby Atmos-ljudsignalen inte överföras.


Dolby Atmos: Om du tittar på innehåll i Dolby Atmos-format, ställ in ljudutgången på din TV till «Pass Through».
TV-inställningar > Hem > Inställningar > Ljud > Digital ljudutgång > Pass Through

HDMI eARC (Enhanced Audio Return Channel) är en uppgraderad version av ARC som stöder ljudformat av högre kvalitet som Dolby Atmos.

Obs! Aktivera “CEC”-funktionen på din TV. När eARC är ansluten kan din TV-fjärrkontroll styra både soundbaren och TV:n samtidigt:
(1) Ström på / Standby
(2) Justera volym


10 ANSLUT TV VIA OPTISK KABEL

1. Kontrollera att din TV har en OPTICAL OUT-port. Använd en optisk kabel för att ansluta TV:ns OPTICAL OUT-port till soundbarens OPTICAL IN-port.



2. Se till att den optiska kabelns kontakt är korrekt isatt enligt bilden. Sätt inte i kontakten upp och ned, eftersom det kan skada den optiska porten.


3. TV-inställningar > Home > Ljud > Digital ljudutgång > PCM



Obs! Om ljud spelas upp via TV:ns interna högtalare, tysta TV:n eller sänk volymen till minimum.


Den optiska porten stöder inte Dolby Atmos. För bästa Dolby Atmos-upplevelse, använd HDMI eARC.

11 ANSLUT VIA BLUETOOTH®



1. Tryck på knappen “ ” på soundbaren eller fjärrkontrollen för Bluetooth®-parkoppling.
2. Öppna Bluetooth®-inställningarna på din telefon, sök efter och välj “Poseidon D60” för att ansluta till soundbaren.
3. Obs! Om soundbaren redan är i Bluetooth®-läge och ansluten till en enhet håller du knappen“ ” intryckt i 3 sekunder för att koppla från den anslutna enheten. Välj sedan soundbaren manuellt på din telefon, dator eller TV för att upprätta en ny Bluetooth®-anslutning.

12 PARKOPPLA SUBWOOFER




Vanligtvis är soundbar och subwoofer förparade.
Om anslutningen bryts, följ stegen nedan.

1. Håll “SUB PAIR” intryckt i 3 sekunder.
   Displayen blinkar “ SUB ” för parkopplingsläge.
2. Håll parkopplingsknappen på subwoofern i 5 sekunder.
3. När parkopplingen lyckas slutar displayen blinka och lampan lyser fast.

13 ÅTERSTÄLL FABRIKSINSTÄLLNINGAR

Håll MUTE-knappen intryckt i 5 sekunder för att återställa fabriksinställningar.




14 JUSTERA SIGNALTONENS VOLYM


Download Ultimea App

Available on the App Store

GET IT ON Google Play

ULTIMEA





Om signaltonen är för hög kan den justeras via ULTIMEA-appen.

1. Skanna QR-koden för att ladda ner ULTIMEA-appen och lägga till soundbaren.
2. Öppna enhetsdetaljer, tryck på Inställningar och välj “Prompt Sound” för att justera.

15 TEKNISKA SPECIFIKATIONER

Model Number	U2520
Power Supply	DC 18V 3A (Soundbar) / AC 100~240V (Subwoofer)
Soundbar Drivers	Soundbar: 2.25" × 3, Surround: 2.25" × 2, Subwoofer: 5.25"
Auto Standby	The soundbar will turn to standby mode if there is no audio signal for 15 minutes. You can set the standby time in the App
Standby Power	<0.5W
Operating Temperature	-10°C – 40°C / 14°F – 104°F
Bluetooth® Version	5.3

Soundbar	400 x 70x 90 mm/15.7" x 2.8" x 3.5"
Subwoofer	155x244x215mm/6.1"x9.6"×8.5"
Surround	135x70x90mm/5.3"x2.8"x3.5"
Packaging	328x440x190mm/12.9"×17.3" x 7.5"
Packaging Weight	6.35 kg /14 lbs

USB Output	5V 500mA
Operating Altitude	2000 meters above sea level
Wall Mount Screw	4 × 32 mm / 0.16" × 1.26"
Bracket Screws Diameter	3 mm / 0.12"
Remote Control Battery Type	2 × AAA (NOT INCLUDED)
Notice: Risk of fire or explosion if the battery is replaced by an incorrect type.	

PROPER DISPOSAL INSTRUCTIONS



This mark shown on the product or its packaging, indicates that this product should not be disposed of with other household waste at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

For indoor use only



This symbol indicates that the product is intended for indoor use only.

Class II equipment



This symbol indicates that the product is Class II equipment.

Waste Electrical & Electronic Equipment

Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

WIRELESS FREQUENCY RANGE AND WIRELESS OUTPUT POWER:

Frequency: 2.402GHz-2.48GHz
The Max. transmit power (Applies only to the EU): 10 dBm

FCC REGULATORY COMPLIANCE

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED WARNINGS

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux
CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes :
1) L'appareil ne doit pas produire de brouillage;
2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
3) The device meets the exemption from the routine evaluation limits in issue6 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.
Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la numéro 6 de RSS 102 etla conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne surl'exposition et la conformité de rf.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.
Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ouémetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

Wireless Capability Description:

The subwoofer is equipped with a wireless signal reception module, enabling it to receive audio signals from the main device for playback. This device only supports wireless signal reception and cannot relay or forward signals.
The two surround speakers in the system are designed for wired connection and do not have the ability to transmit or receive wireless signals.
The remote control uses infrared (IR) technology for device control and does not support any other wireless signal transmission or reception capabilities.

⚠ **CA WARNING:** Can expose you to BPA, a carcinogen, and BPA, a reproductive. toxicant. See www.P65Warnings.ca.gov.

CE WARNINGS

1) Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
2) WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
3) WARNING: The adapter plug is used as disconnect device, the disconnect device shall remain readily operable.
4) Frequency: 2.402GHz-2.48GHz
5) The Max. transmit power: 10 dBm

EU Declaration of Conformity

We (Manufacturer is responsible for this declaration)
Ultimea Technology (Shenzhen) Limited
(Company name)

9th Floor, Building A, Shenzhen Industrial Software Park, Bantian Street, Longgang District, Shenzhen, China 518000
(Company address)

Declare under our sole responsibility that the product
Trade Mark: ULTIMEA
Product Name: Poseidon D60 5.1 Channel Dolby Atmos Soundbar
Model No.: U2520

The product to which this declaration relates is in conformity with the essential requirements set out in the Council Directive on the Approximation of the laws of the Member States relating to the Radio Equipment Directive (2014/53/EU), the Restriction of Hazardous Substances Directive (2011/65/EU), the Electromagnetic Compatibility Directive (2014/30/EU), and the Low Voltage Directive (2014/35/EU). The product is responsible for affixing the CE marking, and the following standards were applied:

EN 55032:2015/A1:2020
EN 55035:2017/A11:2020
EN IEC 61000-3-2:2019/A1:2021
EN 61000-3-3:2013/A2:2021
ETSI EN 301 489-1 V2.2.3 (2019-11)
ETSI EN 301 489-17 V3.3.1 (2024-09)
ETSI EN 300 328 V2.2.2 (2019-07)
EN 50663: 2017
EN IEC 62368-1:2020+A11:2020
IEC 62321-3-1:2013
IEC 62321-4:2013+A1:2017
IEC 62321-5:2013
IEC 62321-6:2015
IEC 62321-7-1:2015
IEC 62321-7-2:2017
IEC 62321-8:2017

Full Name: Yoyo.Yu
Position: Approbation Manager

Signature: 

Place/Date: Shenzhen, China / Sep. 13-2024

Trade Marks:

Dolby, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012–2024 Dolby Laboratories. All rights reserved.

HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by Ultimea Technology (Shenzhen) Limited. is under license. Other trademarks and trade names are those of their respective owners.

General specification (English):

Model: U2520
Sound system: 5.1 channel
Power supply: 18V 3A DC(Soundbar);
100-240V~50/60Hz AC (Subwoofer)
Drivers: 2.25"×3(Soundbar) + 2.25"×2 (Surround)
+5.25"(Subwoofer)
Standby Power: <0.5W
USB Output: 5V 500mA DC
Operating Temperature: -10°C-40°C/14°F-104°F
Operating Altitude: 2000 meters above sea level
Wall Mount Screw: 4 × 32 mm / 0.16" × 1.26"
Bracket Screws Diameter: 3 mm / 0.12"
Remote Control Battery Type: 2 x AAA (NOT INCLUDED)
Notice: Risk of fire or explosion if the battery is replaced by an incorrect type.

Dimensions

・Soundbar dimensions (W x H x D):
400 x 70 x 90 mm / 15.7" x 2.8" x 3.5"
・Subwoofer dimensions (W x H x D):
155 x 244 x 215 mm / 6.1" x 9.6" x 8.5"
・Surround dimensions (W x H x D):
135 x 70 x 90 mm / 5.3" x 2.8" x 3.5"
・Packaging dimensions (W x H x D):
328 x 440 x 190 mm / 12.9" x 17.3" x 7.5"
・Packaging Weight: 6.35 kg / 14 lbs

Power Consumption and Wireless Connection Setup Guide

1. Information on power consumption
This equipment complies with European COMMISSION REGULATION (EU) 2023/826.
・Off: N/A
・Standby (when all wireless connections are deactivated): < 0.5 W
・Networked standby for Soundbar: < 2.0 W
*The duration for the device to enter standby mode can be set in the app. Changing this setting may lead to a significant increase in energy consumption, negatively impacting the environment.
2. The period of time after which the power management function switches the equipment automatically into:

Off	N/A	
Standby	When the soundbar is idle (with no playback or operation) and neither Bluetooth®nor the app is connected.	Switched to standby mode after 15 minutes.
Networked standby	When Bluetooth® or the app is connected.	Switched to networked standby mode after 15 minutes of inactivity in operational mode.

3. If this equipment has the wireless network connections:
How to activate wireless network connections:
・Set up the equipment properly;
・Switch into wireless mode (Bluetooth®);
・Connect with energy using products (e.g. players/ game consoles/ STB (Set-Top Boxes)/ phones/ tablets /PCs). How to deactivate wireless network connections: ・Switch to another channel besides Bluetooth®;
・Then long press on the remote control for more than 3 seconds.

For other languages of the above content
(DE, FR, ES, IT, PT, NL, PL, SV, TR, JP, CN, TC, KO, ID, TH, AR), please scan the QR code

IMPORTANT SAFETY INSTRUCTIONS (English):

1.Please read and retain this manual. Follow all warnings and operate according to the instructions.
2.Do not use the device near water sources, in damp environments, or in the rain. Avoid splashing liquids or placing objects containing liquids (such as vases) on the device.
3.Clean only with a dry cloth. Do not use liquid cleaners.
4.Do not block ventilation openings or install the device in an enclosed space. Ensure proper ventilation and install according to the manufacturer's instructions.
5.Do not install the device near heat sources such as radiators, stoves, or amplifiers. Do not cover the ventilation openings with items such as newspapers or curtains.
6.Use only attachments, stands, or accessories specified by the manufacturer. When using a device with wheels, move with care to avoid tipping.
7.Protect the power cord from being pinched, stepped on, or bent, especially at plugs, outlets, and the point where it exits the device.
8.Do not alter the polarized or grounding-type plug. If the plug does not fit into the outlet, consult an electrician to replace the outlet.
9.Unplug the device during lightning storms or when unused for long periods. To fully disconnect power, unplug the device from the wall outlet and ensure the plug is accessible.
10.Do not place any open flame sources (such as lit candles) on or near the device.
11.Do not attempt to open the device. High voltage inside may be fatal. There are no user-serviceable parts inside. All servicing must be performed by qualified personnel.
12.The installation height of the device must not exceed 2 meters.

Scan QR for safety info / QR-Code für Infos scannen / Scanner le QR pour infos / Escanee QR para info / Scansiona il QR per info / Leia o QR para info / Scan QR-code voor info / Zeskanuj kod QR / Skanna QR för info / QR kodu tara / QRコードをスキャン / 扫码查看安全信息 / 掃碼查看安全資訊 / QR 코드 스캔 / Pindai QR untuk informasi keselamatan / สแกน QR เพื่อดูข้อมูลความปลอดภัย / امسح رمز QR لمعلومات السلامة

ULTIMEA

Product Name: Poseidon D60 5.1 Channel Dolby Atmos Soundbar
Model No.: U2520
HVIN: U2520S3

EC REP

Ultimea GmbH
Buchenring 57, 22359 Hamburg, Germany

UK REP

EVATOST CONSULTING LTD
Office 101 32 Threadneedle Street, London,
United Kingdom, EC2R 8AY

© Ultimea Inc. All rights reserved, registered in the United States and other countries.
801 S. Dupont Ave., Ste G, Ontario, CA, 91761, USA

Made in China
Manufacturer: Ultimea Technology (Shenzhen) Limited
Address: 9th Floor, Building A, Shenzhen Industrial Software Park, Bantian Street, Longgang District, Shenzhen, China 518000

Manufacturer Contact Information:

+1 888-598-8875 (US)
Mon-Fri 9am-5pm (PST)

+49 89-628-25828 (EU)
Mon-Fri 9am-5pm (CET)

support@ultimea.com

support.ultimea.com

If you need our support, kindly reach out to our service team.
We are always glad to help.

Download Ultimea App

GET IT ON Google Play

Available on the App Store

ULTIMEA

Search for “ULTIMEA” on social media.

RoHS

214-240436

FR
Cet appareil, ses accessoires, et cordons se recyclent
REPRISE À LA LIVRAISON
OU
À DÉPOSER EN MAGASIN
OU
À DÉPOSER EN DÉCHÈTERIE
Points de collecte sur www.uefairedemesdechets.fr

Warranty Extension Plan

Regardless of where you purchased your Ultimea product,
you can easily opt for this extended warranty.
Scan to check out our extended warranty options.