ULTIMEA

Dolby Atmos

HDMI
HIGH-DEFINITION MULTIMEDIA INTERFACE

Bluetooth®



Manuale utente


Poseidon M4T


Modello n.: U2522
Soundbar Dolby Atmos 5.1

1 ISTRUZIONI IMPORTANTI DI SICUREZZA


- 1.Leggere e conservare queste istruzioni. Seguire tutte le avvertenze e utilizzare l'apparecchio secondo le istruzioni.
- 2.Non utilizzare l'apparecchio vicino all'acqua, in ambienti umidi o sotto la pioggia. Evitare di versare liquidi sull'apparecchio o di posizionare oggetti contenenti liquidi (come vasi) sopra di esso.
- 3.Pulire solo con un panno asciutto. Non utilizzare detergenti liquidi.
- 4.Non ostruire le aperture di ventilazione né installare l'apparecchio in uno spazio ristretto. Assicurare una ventilazione adeguata e installare l'apparecchio secondo le istruzioni del produttore.
- 5.Non installare l'apparecchio vicino a fonti di calore come radiatori, stufe, amplificatori o altri dispositivi che producono calore. Non coprire le aperture di ventilazione con giornali o tende.
- 6.Utilizzare solo accessori, supporti o dispositivi specificati dal produttore. Quando si utilizzano apparecchi con ruote, prestare attenzione durante gli spostamenti per evitare il ribaltamento.
- 7.Proteggere il cavo di alimentazione da calpestii, schiacciamenti o piegature, in particolare presso le spine, le prese e il punto in cui esce dall'apparecchio.
- 8.Non modificare la polarizzazione o le caratteristiche di messa a terra della spina. Se la spina non si adatta alla presa, consultare un elettricista per sostituire la presa.
- 9.Scollegare il cavo di alimentazione durante i temporali o quando non viene utilizzato per lunghi periodi.
- 10.Non posizionare fonti di fiamma libera, come candele accese, sull'apparecchio.
- 11.Non tentare di aprire l'apparecchio. All'interno è presente alta tensione che può causare scosse elettriche o morte. Tutte le riparazioni devono essere eseguite da personale qualificato.
- 12.L'altezza di installazione dell'apparecchio non deve superare i 2 metri.

2 ELENCO ACCESSORI







Adattatore di alimentazione della soundbar(2m/78")




Cavo di alimentazione del subwoofer(2m/78")



Cavo di connessione surround(6m/236")




Cavo HDMI (1.5m/59")




Cavo ottico digitale(1.5m/59")




Telecomando



Vite di montaggio




Staffa da parete



Tassello da muro

3 CONTROLLI DELLA SOUNDBAR



PANNELLO DI CONTROLLO

1. **"⏻": Pulsante di accensione**
   Premere per accendere / spegnere.

2. **"⏏": Sorgente**
   Premere per cambiare: eARC - OPT(OPTICAL) - Bluetooth® - AUX - USB.


3. **"ᛒ": Bluetooth®**
   Premere per modalità Bluetooth®, associazione automatica.
   Tenere premuto 3 s per scollegare e associare. (ID: Poseidon M4T)

4. **"−": Volume −**

5. **"+": Volume +**


4 TELECOMANDO

1. “⏻” : **Pulsante di accensione**
Premere per accendere / spegnere.
2. “▭”: **eARC**
Premere per passare al canale HDMI eARC.
3. “⇥”: **SOURCE**
Premere per cambiare canale.
4. “▣”: **OPT**
Premere per passare al canale OTTICO.
5. “◎”: **AUX**
Premere per passare al canale AUX.
6. “ᛒ”: **Bluetooth®**
Premere per passare al canale Bluetooth®.
7. “▭”: **USB**
Premere per passare al canale USB.
8. “▣”: **SUB PAIR**
Tenere premuto il pulsante per 3 secondi per mettere la Soundbar in stato di attesa per l'abbinamento con il subwoofer.
9. “ᛞ”: **XUPMIX**
L'impostazione predefinita è “on”, che consente di gestire in modo unificato l'attivazione e la disattivazione delle 6 modalità di effetto sonoro.
Xupmix on: L'audio dei canali surround viene riprodotto utilizzando un ricco segnale multicanale elaborato dall'algoritmo, offrendo un'esperienza di ascolto più immersiva.
Xupmix off: L'audio dei canali surround viene ottimizzato tramite un algoritmo basato sui segnali dei canali sinistro e destro, creando un campo sonoro più ampio.
10. “＋”: **Volume su**
11. “—”: **Volume giù**
12. “<”: **Precedente**
Solo BLUETOOTH® e USB: brano precedente.
13. “>”: **Successivo**
Solo BLUETOOTH® e USB: brano successivo.
14. “⏯”: **Riproduci / Pausa**
Solo BLUETOOTH® e USB.
15. “🔇”: **MUTE**
Muto. Tenere premuto per 5 secondi per reimpostare.
16. “💡”: **LED DIMMER**
Premere per regolare la luminosità del display su 5 livelli.
Tenere premuto per 3 secondi per spegnere il display.
17. “BASS ᛞ”: **BASSMX**
Premere per regolare i bassi.
18. “MIDRANGE”: **MIDRANGE**
Premere per regolare il livello delle frequenze medie.
19. “TREBLE”: **TREBLE**
Premere per regolare il livello degli acuti.
20. “📹”: **MOVIE**
Premere per passare alla modalità FILM, il display mostrerà: "E91".
21. “♫”: **MUSIC**
Premere per passare alla modalità MUSICA, il display mostrerà: "E92".
22. “〰”: **VOICE**
Premere per passare alla modalità VOCE, il display mostrerà: "E93".
23. “🏃”: **SPORT**
Premere per passare alla modalità SPORT, il display mostrerà: "E94".
24. “🎮”: **GAME**
Premere per passare alla modalità GIOCO, il display mostrerà: "E95".
25. “☾”: **NIGHT**
Premere per passare alla modalità NOTTE, il display mostrerà: "E96".




26. “SURROUND”: **SURROUND**
Premere per regolare il livello del suono surround.
27. “PROMPT TONE”: **PROMPT TONE**
Premere per regolare il livello del tono di conferma, il display mostrerà: “Pt 0”, “Pt 1”, “Pt 2”, “Pt 3”.

5 COLLEGAMENTI DEL PANNELLO POSTERIORE




1. **DC IN**
2. **AUX**
3. **OPTICAL**
4. **USB (Supporta MP3 o FLAC)**
5. **HDMI to TV(eARC)**

6 POSIZIONAMENTO DEL SISTEMA



Nota: Posizionare la soundbar all'altezza delle orecchie.


7 INSTALLAZIONE A PARETE




Nota: La staffa da parete utilizzata per i diffusori surround è identica a quella del diffusore principale, quindi la spaziatura verticale dei fori è la stessa della soundbar e anche il metodo di installazione è lo stesso.

8 COLLEGAMENTO E ACCENSIONE

1 Collegare la soundbar all'alimentazione elettrica.




2 Collegare il subwoofer all'alimentazione elettrica.




3 Collegare il subwoofer e i diffusori surround utilizzando il cavo per diffusori surround.

I diffusori satellitari surround sul lato destro avranno interfacce rosse, mentre i diffusori satellitari surround sul lato sinistro avranno interfacce bianche.



4 Inserire le batterie nel telecomando.


Nota: Batterie alcaline consigliate.
Batterie ricaricabili non consigliate.




9. COLLEGAMENTO TV TRAMITE HDMI eARC

1. Collegare un'estremità del cavo HDMI alla porta eARC/ARC del TV.

2. Collegare l'altra estremità alla porta eARC della soundbar.



3. Premere il pulsante "Source" sulla soundbar o sul telecomando per selezionare l'ingresso "eARC".



Nota: Assicurarsi che la porta HDMI del televisore supporti eARC; altrimenti, il segnale audio Dolby Atmos non può essere trasmesso.

Dolby Atmos: Se stai guardando contenuti in formato Dolby Atmos, imposta l'uscita audio del televisore su «Pass Through».
Impostazioni TV > Home > Impostazioni > Audio > Uscita audio digitale > Pass Through


HDMI eARC (Enhanced Audio Return Channel) è una versione aggiornata di ARC che supporta formati audio di qualità superiore come Dolby Atmos.

Nota: Abilitare la funzione "CEC" sul televisore. Quando eARC è collegato, il telecomando del TV può controllare contemporaneamente sia la Soundbar che il televisore:

(1) Accensione / Standby
(2) Regolazione volume


10 COLLEGAMENTO TV TRAMITE CAVO OTTICO

1. Assicurarsi che il televisore disponga di una porta OPTICAL OUT. Utilizzare un cavo ottico per collegare la porta OPTICAL OUT del televisore alla porta OPTICAL IN della soundbar.




2. Assicurarsi che il connettore del cavo ottico sia inserito correttamente, come mostrato nell'illustrazione. Non inserirlo al contrario, poiché potrebbe danneggiare la porta ottica.

3. Impostazioni TV > Home > Audio > Uscita digitale > PCM




Nota: Se l'audio viene riprodotto dagli altoparlanti interni del televisore, disattiva l'audio del televisore o abbassa il volume al minimo.
La porta ottica non supporta Dolby Atmos. Per la migliore esperienza Dolby Atmos, utilizza HDMI eARC.

11. CONNESSIONE BLUETOOTH®



1. Premere il tasto “ ” sulla soundbar o sul telecomando per entrare in modalità di associazione Bluetooth®.
2. Accedere alle impostazioni Bluetooth® del telefono, cercare e selezionare “Poseidon M4T” per connettersi alla soundbar.
3. Nota: Se la soundbar è già in modalità Bluetooth® e connessa a un dispositivo, tenere premuto il pulsante “ ” per 3 secondi per disconnettere il dispositivo attualmente collegato. Selezionare quindi manualmente la soundbar sul telefono, PC o televisore per stabilire una nuova connessione Bluetooth®.

12 RIASSOCIARE IL SUBWOOFER




Normalmente, soundbar e subwoofer sono già associati.
Se la connessione si interrompe, seguire i passaggi seguenti:

1. Tenere premuto “SUB PAIR” per 3 secondi. Il display lampeggia “ ” indicando la modalità di associazione.
2. Tenere premuto il pulsante di pairing sul retro del subwoofer per 5 secondi.
3. Quando l’associazione è riuscita, il display smette di lampeggiare e la spia resta accesa.

13 RIPRISTINARE LE IMPOSTAZIONI DI FABBRICA

Tenere premuto il tasto MUTE per 5 secondi per ripristinare le impostazioni di fabbrica.




14 REGOLARE IL VOLUME DEL SUONO DI AVVISO


Download Ultimea App

Available on the App Store

GET IT ON Google Play

ULTIMEA





Se il suono di avviso è troppo forte, è possibile regolarlo tramite l'app ULTIMEA.

1. Scansiona il codice QR per scaricare l'app ULTIMEA, quindi aggiungi la soundbar.
2. Apri i dettagli del dispositivo, tocca Impostazioni e seleziona "Prompt Sound " per regolare.

15 SPECIFICHE TECNICHE

Model Number	U2522
Power Supply	DC 18V 3A (Soundbar) / AC 100~240V (Subwoofer)
Soundbar Drivers	Soundbar: 2.25" × 3, Surround: 2.25" × 2, Subwoofer: 5.25"
Auto Standby	The soundbar will turn to standby mode if there is no audio signal for 15 minutes. You can set the standby time in the App
Standby Power	<0.5W
Operating Temperature	-10°C – 40°C / 14°F – 104°F
Bluetooth® Version	5.3

Soundbar	400 x 70x 90 mm/15.7" x 2.8" x 3.5"
Subwoofer	155x244x215mm/6.1"x9.6"×8.5"
Surround	135x70x90mm/5.3"x2.8"x3.5"
Packaging	328x440x190mm/12.9"×17.3" x 7.5"
Packaging Weight	6.35 kg /14 lbs

USB Output	5V 500mA
Operating Altitude	2000 meters above sea level
Wall Mount Screw	4 × 32 mm / 0.16" × 1.26"
Bracket Screws Diameter	3 mm / 0.12"
Remote Control Battery Type	2 × AAA (NOT INCLUDED)
Notice: Risk of fire or explosion if the battery is replaced by an incorrect type.	

PROPER DISPOSAL INSTRUCTIONS



This mark shown on the product or its packaging, indicates that this product should not be disposed of with other household waste at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

For indoor use only



This symbol indicates that the product is intended for indoor use only.

Class II equipment



This symbol indicates that the product is Class II equipment.

Waste Electrical & Electronic Equipment

Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

WIRELESS FREQUENCY RANGE AND WIRELESS OUTPUT POWER:

Frequency: 2.402GHz-2.48GHz
The Max. transmit power (Applies only to the EU): 10 dBm

FCC REGULATORY COMPLIANCE

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED WARNINGS

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux
CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes :
1) L'appareil ne doit pas produire de brouillage;
2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
3) The device meets the exemption from the routine evaluation limits in issue6 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.
Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la numéro 6 de RSS 102 etla conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne surl'exposition et la conformité de rf.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.
Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ouémetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

Wireless Capability Description:

The subwoofer is equipped with a wireless signal reception module, enabling it to receive audio signals from the main device for playback. This device only supports wireless signal reception and cannot relay or forward signals.
The two surround speakers in the system are designed for wired connection and do not have the ability to transmit or receive wireless signals.
The remote control uses infrared (IR) technology for device control and does not support any other wireless signal transmission or reception capabilities.

⚠ **CA WARNING:** Can expose you to BPA, a carcinogen, and BPA, a reproductive. toxicant. See www.P65Warnings.ca.gov.

CE WARNINGS

1) Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
2) WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
3) WARNING: The adapter plug is used as disconnect device, the disconnect device shall remain readily operable.
4) Frequency: 2.402GHz-2.48GHz
5) The Max. transmit power: 10 dBm

EU Declaration of Conformity

We (Manufacturer is responsible for this declaration)
Ultimea Technology (Shenzhen) Limited
(Company name)

9th Floor, Building A, Shenzhen Industrial Software Park, Bantian Street, Longgang District, Shenzhen, China 518000
(Company address)

Declare under our sole responsibility that the product
Trade Mark: ULTIMEA
Product Name: Poseidon M4T 5.1 Channel Dolby Atmos Soundbar
Model No.: U2522

The product to which this declaration relates is in conformity with the essential requirements set out in the Council Directive on the Approximation of the laws of the Member States relating to the Radio Equipment Directive (2014/53/EU), the Restriction of Hazardous Substances Directive (2011/65/EU), the Electromagnetic Compatibility Directive (2014/30/EU), and the Low Voltage Directive (2014/35/EU). The product is responsible for affixing the CE marking, and the following standards were applied:

EN 55032:2015/A1:2020

EN 55035:2017/A11:2020

EN IEC 61000-3-2:2019/A1:2021

EN 61000-3-3:2013/A2:2021

ETSI EN 301 489-1 V2.2.3 (2019-11)

ETSI EN 301 489-17 V3.3.1 (2024-09)

ETSI EN 300 328 V2.2.2 (2019-07)

EN 50663: 2017

EN IEC 62368-1:2020+A11:2020

IEC 62321-3-1:2013

IEC 62321-4:2013+A1:2017

IEC 62321-5:2013

IEC 62321-6:2015

IEC 62321-7-1:2015

IEC 62321-7-2:2017

IEC 62321-8:2017

Full Name: Yoyo.Yu
Position: Approbation Manager

Signature: 

Place/Date: Shenzhen, China / Sep. 13-2024

Trade Marks:

Dolby, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2012–2024 Dolby Laboratories. All rights reserved.

HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Ultimea Technology (Shenzhen) Limited. is under license. Other trademarks and trade names are those of their respective owners.

General specification (English):

Model: U2522
Sound system: 5.1 channel
Power supply: 18V 3A DC(Soundbar);
100-240V~50/60Hz AC (Subwoofer)
Drivers: 2.25"×3(Soundbar) + 2.25"×2 (Surround)
+5.25"(Subwoofer)
Standby Power: <0.5W
USB Output: 5V 500mA DC
Operating Temperature: -10°C-40°C/14°F-104°F
Operating Altitude: 2000 meters above sea level
Wall Mount Screw: 4 × 32 mm / 0.16" × 1.26"
Bracket Screws Diameter: 3 mm / 0.12"
Remote Control Battery Type: 2 x AAA (NOT INCLUDED)
Notice: Risk of fire or explosion if the battery is replaced by an incorrect type.

Dimensions

・Soundbar dimensions (W x H x D):
400 x 70 x 90 mm / 15.7" x 2.8" x 3.5"
・Subwoofer dimensions (W x H x D):
155 x 244 x 215 mm / 6.1" x 9.6" x 8.5"
・Surround dimensions (W x H x D):
135 x 70 x 90 mm / 5.3" x 2.8" x 3.5"
・Packaging dimensions (W x H x D):
328 x 440 x 190 mm / 12.9" x 17.3" x 7.5"
・Packaging Weight: 6.35 kg / 14 lbs

Power Consumption and Wireless Connection Setup Guide

1. Information on power consumption
This equipment complies with European COMMISSION REGULATION (EU) 2023/826.
・Off: N/A
・Standby (when all wireless connections are deactivated): < 0.5 W
・Networked standby for Soundbar: < 2.0 W
*The duration for the device to enter standby mode can be set in the app. Changing this setting may lead to a significant increase in energy consumption, negatively impacting the environment.
2. The period of time after which the power management function switches the equipment automatically into:

Off	N/A	
Standby	When the soundbar is idle (with no playback or operation) and neither Bluetooth® nor the app is connected.	Switched to standby mode after 15 minutes.
Networked standby	When Bluetooth® or the app is connected.	Switched to networked standby mode after 15 minutes of inactivity in operational mode.

3. If this equipment has the wireless network connections:
How to activate wireless network connections:
・Set up the equipment properly;
・Switch into wireless mode (Bluetooth®);
・Connect with energy using products (e.g. players/ game consoles/ STB (Set-Top Boxes)/ phones/ tablets /PCs). How to deactivate wireless network connections: ・Switch to another channel besides Bluetooth®;
・Then long press on the remote control for more than 3 seconds.

For other languages of the above content
(DE, FR, ES, IT, PT, NL, PL, SV, TR, JP, CN, TC, KO, ID, TH, AR), please scan the QR code

IMPORTANT SAFETY INSTRUCTIONS (English):

1.Please read and retain this manual. Follow all warnings and operate according to the instructions.
2.Do not use the device near water sources, in damp environments, or in the rain. Avoid splashing liquids or placing objects containing liquids (such as vases) on the device.
3.Clean only with a dry cloth. Do not use liquid cleaners.
4.Do not block ventilation openings or install the device in an enclosed space. Ensure proper ventilation and install according to the manufacturer's instructions.
5.Do not install the device near heat sources such as radiators, stoves, or amplifiers. Do not cover the ventilation openings with items such as newspapers or curtains.
6.Use only attachments, stands, or accessories specified by the manufacturer. When using a device with wheels, move with care to avoid tipping.
7.Protect the power cord from being pinched, stepped on, or bent, especially at plugs, outlets, and the point where it exits the device.
8.Do not alter the polarized or grounding-type plug. If the plug does not fit into the outlet, consult an electrician to replace the outlet.
9.Unplug the device during lightning storms or when unused for long periods. To fully disconnect power, unplug the device from the wall outlet and ensure the plug is accessible.
10.Do not place any open flame sources (such as lit candles) on or near the device.
11.Do not attempt to open the device. High voltage inside may be fatal. There are no user-serviceable parts inside. All servicing must be performed by qualified personnel.
12.The installation height of the device must not exceed 2 meters.

Scan QR for safety info / QR-Code für Infos scannen / Scanner le QR pour infos / Escanee QR para info / Scansiona il QR per info / Leia o QR para info / Scan QR-code voor info / Zeskanuj kod QR / Skanna QR för info / QR kodu tara / QRコードをスキャン / 扫码查看安全信息 / 掃碼查看安全資訊 / QR 코드 스캔 / Pindai QR untuk informasi keselamatan / สแกน QR เพื่อดูข้อมูลความปลอดภัย / امسح رمز QR لمعلومات السلامة

ULTIMEA

Product Name: Poseidon M4T 5.1 Channel Dolby Atmos Soundbar
Model No.: U2522
HVIN: U2522

EC REP
Ultimea GmbH
Buchenring 57, 22359 Hamburg, Germany

UK REP
EVATOST CONSULTING LTD
Office 101 32 Threadneedle Street, London,
United Kingdom, EC2R 8AY

© Ultimea Inc. All rights reserved, registered in the United States and other countries.
801 S. Dupont Ave., Ste G, Ontario, CA, 91761, USA

Made in China
Manufacturer: Ultimea Technology (Shenzhen) Limited
Address: 9th Floor, Building A, Shenzhen Industrial Software Park, Bantian Street, Longgang District, Shenzhen, China 518000

Manufacturer Contact Information:

+1 888-598-8875 (US)
Mon-Fri 9am-5pm (PST)

+49 89-628-25828 (EU)
Mon-Fri 9am-5pm (CET)

support@ultimea.com

support.ultimea.com

If you need our support, kindly reach out to our service team.
We are always glad to help.

Download Ultimea App

GET IT ON Google Play

Available on the App Store

ULTIMEA

Search for “ULTIMEA” on social media.

RoHS

FR Cet appareil, ses accessoires, et cordons se recyclent
REPRISE À LA LIVRAISON OU À DÉPOSER EN MAGASIN OU À DÉPOSER EN DÉCHÈTERIE
Points de collecte sur www.uefairedemesdechets.fr

Warranty Extension Plan

Regardless of where you purchased your Ultimea product, you can easily opt for this extended warranty.
Scan to check out our extended warranty options.